



Rubber mat over tunnel



3V0 061 580

ŠKODA Superb (3V)

Material: Rubber
Colour: Black

Protection | Rigorous tests | Resistance and durability

The rubber mat over the central tunnel makes for a logical accessory of the rear foot mats as it maximises the effectiveness of **floor protection**. **It protects the central tunnel** from impurities and dirt from the passenger's shoes at the rear seats. This protection appears to be a necessity especially when travelling at full capacity. The rubber mat over the tunnel is inserted first, followed by the rear mats. This is the only way to make the mat adhere to the central tunnel without shifting around. The mats have undergone **rigorous tests** of their **resistance** and **shape profile stability**, which have confirmed their premium parameters. Apart from the mechanical stability, their features also include easy maintenance. Any dirt can be easily removed using a common non-abrasive soap cleaning agent.

Fitting time: 20 TU

Contents of the kit: Rubber mat over tunnel, installation manual

Fitting: Insert loosely onto the central tunnel of the car, with the lower edges slipped under the rear rubber foot mats

Maintenance: Standard soap-based cleaning agents. Don't use abrasive cleaning agents and solvents.

Advice: We recommend to combine this product with the rubber foot mats

Warranty: 24 months (does not apply regular wearing)

Weight: 0.2 kg

Related Products:

Front rubber foot mats – left hand steering / 3V1 061 551

Front rubber foot mats – right hand steering / 3V2 061 551

Rear rubber foot mats /

3V0 061 551

COMFORT AND UTILITY