



HONDA INSTALLATION INSTRUCTIONS

Accessory
ILLUMINATED CONSOLE KIT

Application
2016 CIVIC

Publications No.
VERSION 1
Issue Date
OCT 2015

PARTS LIST


Left light



Right light




Light harness



4 Wire ties



Fuse label




6 Self-tapping screws



Urethane tape



Template



Aluminum tape



TOOLS AND SUPPLIES REQUIRED

Phillips screwdriver

10 mm Open end wrench

Ratchet

10 mm Socket

Diagonal cutters

Isopropyl alcohol

Shop towel

Tape

Scissors

Masking tape

Pushpin

Eye protection (face shield, safety goggles, etc.)

Drill


3 mm, 6 mm, 7 mm, 8 mm, and 10 mm Drill bits

File

The following tools are available through the Honda Tool and Equipment Program. On the iN, click on Service > Service Bay > Tool and Equipment Program, then enter the number under "Search." Or, call 888-424-6857.

- Trim Tool Set (T/N SOJATP2014)
- Plastic Trim Tool (T/N SILTRIMTL10)


Illustration of the Illuminated Console in the Vehicle




INSTALLATION

Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."


1. Disconnect the negative cable from the battery.
2. Remove the left console armrest.




3. Apply tape to the area shown.



4. Remove the left center console trim.




5. Remove the right console armrest.



QE30559CJ


6. Apply tape to the area shown.



RIGHT CENTER
CONSOLE TRIM

QE30514BJ


7. Remove the right center console trim.



RIGHT CENTER
CONSOLE TRIM

QE30516CJ

8. Remove the A/C control unit and unplug the vehicle connectors.



A/C CONTROL
UNIT

VEHICLE
CONNECTORS


QE30523BJ

9. Remove the shift lever console panel:


A/T Models

- Open the center console armrest, and slide the sliding tray (if equipped) and the beverage holder rearward.
- Remove the shift lock release cover with a plastic trim tool.
- Insert the key into the shift lock release slot, and move the shift lever knob to the D position.


NOTE: Make sure to apply the parking brake.



- Remove the console panel and unplug the vehicle connectors.




- Remove the shift lever panel




M/T Models

- Lower the shift lever boot to release two retaining tabs from the boot.
- Remove the shift lever knob.




QE30541AJ

- Remove the shift lever panel and unplug the vehicle connectors.




QE30542AJ


10. Remove the upper tray mat.




11. Remove the console panel.




12. Remove the left lower trim.




13. Remove the right lower trim.




14. Using scissors, cut the template into six pieces.



15. Attach the templates to the left lower trim with masking tape.




16. Using a pushpin, pierce the center of four marks on the templates.




17. Remove the templates.


18. While wearing eye protection, drill the three pierced marks with a 3 mm drill bit, then finish with a 7 mm drill bit.




19. While wearing eye protection, drill the remaining pierced mark with a 3 mm drill bit, with a 6 mm drill bit, with an 8 mm drill bit, then finish with a 10 mm drill bit.
20. Using a file, remove any burrs from the holes.
21. Attach the templates to the right lower trim with masking tape.



22. Using a pushpin, pierce the center of three marks on the templates.




23. Remove the templates.
24. While wearing eye protection, drill the two pierced marks with a 3 mm drill bit, then finish with a 7 mm drill bit.




25. While wearing eye protection, drill the remaining pierced mark with a 3 mm drill bit, with a 6 mm drill bit, with an 8 mm drill bit, then finish with a 10 mm drill bit.
26. Using a file, remove any burrs from the holes.

27. Attach the template to the console panel with masking tape.



QE32409AJ


28. Using a pushpin, pierce the center of the mark on the template.



QE32410BJ


29. Remove the template.

30. While wearing eye protection, drill the pierced mark with a 3 mm drill bit, then finish with a 7 mm drill bit.




QE32411AJ

31. Using a file, remove any burrs from the hole.
32. Route the left light harness through the 10 mm hole, and align the left light with the left lower trim.




QE32412AJ

33. Secure the left light to the left lower trim with three self-tapping screws.



QE32413AJ


34. Using isopropyl alcohol on a shop towel, thoroughly clean the left lower trim where the aluminum tape will attach.



QE32414BJ


35. Using scissors, cut one aluminum tape into three pieces, secure the left light harness to the left lower trim with one of the pieces of aluminum tape.

36. Route the right light harness through the 10 mm hole, and align the right light with the right lower trim.




QE32415AJ

37. Secure the right light to the right lower trim with two self-tapping screws.



QE32416AJ


38. Using isopropyl alcohol on a shop towel, thoroughly clean the right lower trim where the aluminum tape will attach.



QE32417BJ

39. Secure the right light harness to the right lower trim with one piece of aluminum tape.


40. Install the left and right lower trims to the console panel.



QE32418BJ


41. Secure the right light to the console panel with one self-tapping screw.

42. Using isopropyl alcohol on a shop towel, thoroughly clean the fuse case where the fuse label will attach.




QE32419AJ

43. Attach the fuse label to the light harness fuse case.
 44. Route the light harness as shown. Align the green tape on the light harness with the vehicle clip, and secure the light harness to the vehicle harness with one wire tie.




QE32420BJ

45. Secure the light harness 2-pin connector to the vehicle harness with one wire tie.




QE32421BJ

46. Plug the vehicle harness 4-pin connector into the light harness 4-pin connector, and secure the 4-pin connectors to the vehicle harness with one wire tie.



QE32422BJ


47. Install the console panel.



QE32423BJ


48. Using scissors, cut one urethane tape in half, and attach one piece of urethane tape around the right light harness 2-pin connector.

49. Plug the light harness 2-pin connector into the right light harness 2-pin connector, and secure the 2-pin connectors to the console panel with one wire tie.




QE32424CJ

50. Plug the left light harness 2-pin connector into the light harness 2-pin connector.



QE32425BJ

51. Install the shift lever panel.



52. Plug the light harness 4-pin connector into the ECON or SPORT switch, and reinstall the console panel.
53. Check that all wire harnesses are routed properly and all connectors are plugged in.
54. Install all removed parts.
55. Connect the negative cable to the battery.
56. Press and hold the audio unit power button for 2 seconds to restore the audio and navi (if equipped) system functions.
57. Set the clock.
58. If necessary, restore the systems back to normal operation as described in the Service Information.

Check the Operation of the Illuminated Console

59. With the light switch set to the “ ” or “ ” position, the illuminated console is on.
60. When the headlight switch is in the “AUTO” position, the illuminated console is on with the parking lights or headlights.
61. Check that the illuminated console brightness varies along with the instrument panel brightness by turning the brightness control knob.
62. If the illuminated console does not come on, check the fuse and all connectors.

